


ReconHub Dashboard



Clear Alarms
Tap to silence all alarms. They will stay silent until another issue is detected.

Snapshot
Tap to take a screenshot of the current screen.

ECU & Run Status
Flip card for more information on ECU and run status.

Status Bar
Shows if Wi-Fi (data), gateway, and work switch are connected or disconnected.

Job Presets
Contains configurations for specific applications. Create a preset to begin monitoring.

Mass Flow
Represents product flow for all runs in one airstream. This number changes with changes in ground speed, product type, and application rates.

ReconBlockage™

CLEAR ALARMS SNAPSHOT

DATA GATEWAY WORK SWITCH

0317 JOB PRESETS

MANIFOLDS

PRODUCT

DASHBOARD ALARMS SETTINGS



Monitoring ECU & Run Status

