

URGENT - INFORMATION NOTICE

DOCUMENT NUMBER: 600870-000039

SUBJECT: INTELLIGENT AG APPS – iOS 14 SECURITY RESTRICTION

DATE: SEPTEMBER 16, 2020

This information notice is to inform all Intelligent Ag dealers and customers about the recent release of iOS 14 and to recommend disabling iOS updates until Intelligent Ag releases updated apps.

Affected Parts

APP NAME	APP VERSION	APP ICON	PROBLEM
Recon Blockage Monitor iPad application	2.6.457 and older	RECON Blockage Monitor	Downloading iOS 14 will render version 2.6.257 and older inoperable.
Recon SpreadSense iPad application	1.3.173 and older	RECON Spread Sense.	Downloading iOS 14 will render version 1.3.173 and older inoperable.



About

On September 16, 2020, Apple released iOS 14. This update contains a new network security restriction which affects network device discovery. This security change disables the connection between the Intelligent Ag iPad applications and access points. The current application versions (listed on page 1) will not work with iOS 14.

Intelligent Ag is working diligently to implement the new security requirements and anticipates this update will take approximately 1 week to be released into the App Store.

There is no easy way to revert an iPad back to a prior iOS version. For now, we are recommending that all Intelligent Ag application users do not update to iOS 14, and if enabled, disable automatic iOS updates until we are able to incorporate the new network security requirements.

Disabling Automatic iOS Updates

Follow the steps below to disable automatic iOS updates on your iPad.


1. On the iPad home screen, tap **Settings.**





- General Settings ked Up 1 About GM Garrett Maurer Software Update Airplane Mode Pad Not Backed Ur AirDron AirDron * Bluetooth plane Mode 1 iPad Storage iPad Storage unds 6 Do Not Disturb Notification Date & Time X Screen Time Date & Time Sounds 6 Do Not Disturb Fonts Language & Regi play & Brightnes AA Dictionary Dictionary Home Screen & Dock Control Cente VPN Æ AA Display & Brig * Siri & Search -Touch ID & Pa Reset Reset Siri & Search 8 Privacy
- 2. Tap General on the left navigation, then tap Software Updates on the right.

3. Tap Automatic Updates, then disable the Automatic Updates switch.





- 24 JUL Wegst

 24 JUL Wegst

 24 JUL Wegst

 26 JUL Not Backed Up

 26 Airplane Mode

 27 Airplane Mode

 28 Airplane Mode

 29 Wi-Fi

 30 Mirflactions

 29 Do Not Disturb

 29 Screen Time

 20 General

 20 General

 20 Airplane Mode

 20 Screen Time

 20 Control Centre:

 30 Instream Bock

 30 Accessibility

 31 Windpace

 32 Streen Time

 32 Control Centre:

 33 Windpace

 35 Nothon De Dock

 35 Notifications

 36 Control Centre:

 36 Windpace

 37 Nothon De Dock

 38 Windpace

 39 Touch De Assocede

 39 France
- 4. Verify that the setting is turned off by navigating back to the Software Updates screen.

Document References

This document and all other Intelligent Ag support documentation is found at <u>www.intelligentag.com/support.</u>

Contact

Questions? Contact Intelligent Ag Product Support Canadian Product Support: 1-306-993-1156 United States Product Support: 1-701-436-1219 Or email us at support@intelligentag.com